

Watershed-Based NPS Planning

- Introduction and Background
- Basic Components of a Watershed Plan
- Tools for Assessment
- Tools for Planning
- Tools for Implementation




Introduction and background


- Continued focus on impaired waters
- Watershed plans to be developed before BMPS are selected
- 319-funded work plans should be based on the overall watershed plan
- New focus on:
 - Quantitative analysis of current loadings
 - Estimates of pollutant load reductions needed
 - Load reduction potential of specific, planned BMPs
 - Phased implementation of the watershed plan


What is a watershed approach and why use it?


- Geographic Focus
 - Focuses on the resource, not the program
- Sound Science
 - Coordinates data collection efforts, leverages limited resources, streamlines reporting requirements
- Partnerships/stakeholder involvement
 - Builds public support to help ensure lasting solutions
- Iterative Process



_				
_				
_				
_				
_				
_				
_				
_				


























Watershed-Based NPS Plans


- a. Identify stressors & sources to be controlled
- b. Estimate load reductions expected from BMPs
- c. Describe mgmt measures & targeted critical areas
- d. Estimate TA, \$\$, & source required for implementation
- e. Describe info & education needed to promote $\ensuremath{\mathsf{BMPs}}$
- f. Develop schedule for implementation of BMPs, assign tasks
- g. Describe interim, measurable milestones
- h. Identify criteria to measure progress
- i. Develop monitoring component

Source: US EPA 2004 319 Supplemental Guidelines





Contents of the Watershed Plan Introduction Plan area & description, partners, background Water quality information & analysis WQ goals, monitoring/assessment results Key pollutants / stressors, sources, current loads Proposed management measures Load reductions needed, BMP types proposed Reductions expected from BMPs, installation sites Implementation plan Public info/education & outreach/involvement plan BMP/\$\$/TA support sources, project schedule & costs Monitoring and adaptive management approach Interim measurable milestones, load reduction criteria Evaluation framework, monitoring plan & partners



Gather Data

- Build on earlier efforts
 - What has already been done?
 - Existing data sets and reports
 - Septic system inventories
 - 305(b) report
 - Wetland inventories
- Consider stakeholder concerns



Gather Data, cont.

- Who has the data?
 - Tribe
 - Neighboring county or town/city agencies
 - State agencies
 - Federal agencies
 - Area environmental or watershed organizations

Types of Data for Watershed Characterization

- Physical and Natural Features
 - Watershed boundaries
 - Hydrology
 - Topography
 - Soils
 - Climate
 - Habitat Wildlife
- Land Use and
- Population Characteristics Land use and land cover
 - Existing management practices
 - Demographics

- Waterbody Conditions
 - Water quality standards
 - 305(b) report303(d) list

 - TMDL reports
 - Source Water Protection Areas
- Pollutant Sources
 - Point sources
 - Nonpoint sources
- **Waterbody Monitoring** Data
 - Water quality data
 - Flow data
 - Biological data

Sample Data Sources • Watershed Coverages: - 8-digit: http://water.usgs.gov/GIS/huc.html 14-digit: www.ncgc.nrcs.usda.gov/products/datasets/watershed - Check tribal or state agencies for small watershed coverages • EPA Reach Files - I.D. and interconnect the stream reaches all over U.S. 3 versions RF1, RF2, RF3-Alpha (most detailed) www.epa.gov/waterscience/ftp/basins/gis_data/huc/ • Elevation Data USGS: http://edc.usgs.gov/geodata GIS data depot: http://data.geocomm.com • Land Use/Population - USGS: http://edc.usgs.gov/geodata - EPA: www.epa.gov/nrlc/nlcd.html • BLM Management Plans www.blm.gov/planning/plans.html Other Data Sources • State 303 (d) lists and TMDL reports - www.epa.gov/owow/tmdl • Point source discharge permits - www.epa.gov/enviro/html/pcs/index.html • Census of Agriculture – www.nass.usda.gov/census • Septic tank use - http://guickfacts.census.gov/ Review Data and Identify Gaps • Do you have enough data to start the analysis? • What is the quality of the data? • Do we need to collect more data?

 Conduct visual assessments and research local knowledge

Stream Visual Assessment Protocol
Assessment Totocol
A TOP OF THE PARTY
A STATE OF THE STATE OF
2112

Review and Analyze Data

Minimum Element

a. An identification of the causes and sources or groups of similar sources that will need to be controlled to achieve the load reductions estimated in this watershed-based plan.

Characterizing causes & sources

- By "loads"
 - Kilograms per day
 - Pounds per week
 - Tons per month
- Or by other means . . .
 - Concentration-based expression of the "load" (e.g., milligrams per liter)
 "mg/L x L/day = mg/day [C = m/v]
 # of miles of streambank needing stabilization or vegetation

 - # of AFOs requiring nutrient plans
 - % of urban area to be 'perforated'



Understanding pollution sources

- Point-source discharges (NPDES facilities)
 Info is available on the discharges (DMRs, etc.)

 - Some are steady-flow, others are precip-driven
- Nonpoint sources (polluted runoff)

 All are (mostly) precip-driven

 Calculating the "wash-off, runoff" load is tough!

 Literature values & etc. can be used to estimate

 Tribes can use BPJ and narrative descriptions
- Air / atmospheric deposition

 Can be significant in some locations





Pollutant		Potential Sources	Impacts on Waterbody Uses	
	Point Sources	Nonpoint Sources	illipacts on waterbody oses	
Pathogens	WWTPs CSOs/SSOs Permitted CAFOs Discharges from meat processing facilities Landfills	Animals (domestic, wildlife, livestock) Malifunctioning septic systems Pastures Boat pumpout facilities Land application of manure Land application of wastewater	Primarily human health risks Risk of liness from ingestion or from contact with contaminated water through recreation increased cost of treatment of drinkin water supplies Shelifish bed closures	
Metals	Urban runoff WWTPs CSO/SSOs Landfills Industrial facilities Mine discharges	Abandoned mine drainage Hazardous waste sites (unknown or partially treated sources) Marinas	Aquatic life impairments (e.g., reduce fish populations due to acuterichronic concentrations or contaminated sediment) Drinking water supplies (elevated concentrations in source water) Fish contamination (e.g., mercury)	
Nutrients	WWTPs CSOS/SSOs CAFOs Discharge from food-processing facilities Landfills	Cropland (fertilizer application) Landscaped spaces in developed areas (e.g., lamits, god course) Asimate (domestic, wicatie, livestock) Mallanciccinity aspot systems Pastures Boat pumpout Land application of manure or wasteracter	Acquaic file impairments (e.g., effects from excess plant grown), not continued to the continued of the continued to the continued continued to the continued continued to the continued continued to the continue	

Pollutant		Potential Sources	Impacts on Waterbody Uses	
Pollutant	Point Sources	Nonpoint Sources	impacts on waterbody uses	
Sediment	WWTPs Urban stormwater systems	Agriculture (cropland and pastureland erosion) Silviculture and timber harvesting Rangeland erosion Excessive streambank erosion Construction Roads Urban runoff Landstides Abandoned mine drainage Stream channel modification	Filis pools used for refuge and rearing Filis interstitial spaces between gravel (reduces spanning habitat by regular (reduces spanning habitat by regular (reduces) spanning habitat by regular exchange) Whin suspended, prevents fish from seeing food and can clog gills, high levels of suspended sediment can cause fish to avoid the shear Tastelodor problems in drinking water fingels swimming blooting because of physical attention of the channel indirect impacts on recreations for him.	
Temperature	WWTPs Cooling water discharges (sower plants and other industrial sources) Urban stormwater systems	Lack of riparian shading Shallow or wide channels (due to hydrologic modification) Hydroelectric dams Urban unord (warmer runoff from impervious surfaces) Sedment (douby water absorbs more heat than clear water) Abandoned mine drainage	Causes lethal effects when temperature secred solerane limit increases metabolism results in high oxygen demand for aquate organisms; increases tood requirements Decreases growth rates and DO influences tempor for a progration increases rates of periodosynthesis increases rates of periodosynthesis (increases algal growth, depletes oxygen through plant decomposition) Causes excess plant growth.	

Pollutant	Central business district	Other commercial	Industrial	Single family res.	Multi-family res.	Cropland	Pasture	Forest	Open
TSS	1080	840	56	17	440	450	340	85	7
COD	1070	1020	63	28	330	n.a.	n.a.	n.a.	2.0
Pb	7.1	3.0	2.0 - 7.1	0.1	0.7	0.005 - 0.006	0.003 - 0.015	0.01 - 0.03	n.a.
Zn	3.0	3.3	3.5 - 12	0.22	0.33	0.03 - 0.08	0.02 - 0.17	0.01 - 0.03	n.a.
Cu	2.1	n.a.	0.33 - 1.1	0.03	0.33	0.01 - 0.06	0.02 - 0.04	0.02 - 0.03	n.a.
NO3+NO2-N	4.5	0.67	0.45	0.33	3.8	7.9	0.33	0.56	0.33
TKN	15	15	2.2 - 15	1.1 - 5.6	3.4 - 4.5	1.7	0.67	2.9	1.7
TP	2.8	2.7	0.9 - 4.0	0.2 - 1.5	1.3 - 1.6	0.1 - 3.0	0.07 - 3.0	0.02 - 0.45	0.06

Identification of causes & sources

- What "pollutants" are you dealing with?
 - Chemical or other stressors or causes of impairmen
- How big is the problem for each?
- How do you know?
 - Did you "measure" them?Did you estimate? How?
- Where are they coming from?
 - Can you put the info on a map?
- Can you estimate the % from each source?



Identifying stressors and sources

- Identify specific causes & sources of water quality impairments or threats
 - Examples: metals from abandoned mine lands, sediment & high flows from urban runoff, habitat loss from channelization, etc.
- Quantify or estimate pollutant sources requiring controls
 - Examples: # of feedlots needing upgrades plus rough average of cattle per lot; number of mine sites needing treatment with estimates and general profiles of flows, etc.
 - Can "bundle" stressors and/or sources



Analyze the Data

- Types of Data Analysis
 - Summary Statistics
 - Spatial Analysis
 - Temporal Analysis
 - Stressor Identification

Examples of Sources You Might Miss Without a Watershed Tour

- · Streambank erosion
- Streambank erosion
 Straight pipes
 Livestock (near or with)
- Wildlife (e.g., waterfowl populations on lakes and open streams)
- Illegal dumping
- Use a combination of techniques
- Consider geographic variations
- Revisit stakeholder concerns

The Bottom Line from US EPA:

- Reasonable efforts needed to ID stressors/sources
- Assessment & other data don't have to be exhaustive, but should be indicative
- Preliminary info & estimates can be modified & corrected over time, if necessary

